

# GET STARTED

1. **Log into the computer** using active cougar.net credentials.

Example: jcougar@cougar.net.uh.edu

2. **Power ON** the touch control panel.

3. Select the “**source**” to present materials to the audience.

4. Select the “**destination**” display to send to the projector and/or TV room monitors.

## Source

### Desktop PC (Main) –

Displays one podium computer monitor.

### Desktop PC (Extended) –

Displays left and right podium computer monitors.

### Laptop –

Displays connected external device.

### ShareLink –

Displays mobile wireless device.

## Destination

### Projectors/Confidence Monitor –

The primary display devices.

### Side Displays –

Secondary monitors displaying extended view.

**Projector Power** – When using displays only.



## Camera Presets

**Tracking** – Camera follows the presenter around the room.

**Lectern** – Camera stays focused on the podium. No tracking.

**Full View** – Camera captures the entire room (including presenter). No tracking.

**Video Mute** – Makes the signal from all displays go blank without turning off.

**Swap** – Switches room displays (projector and TV monitors).

**Mic Volume** – Controls podium and wireless microphone intensity.

**Room Volume** – Controls the volume intensity of the room speaker system.

**Help?** – Press for Help FAQ's and the Tech support phone number.

**Power Down** – Shuts off projector, TV room monitors, and touch control panel.